

MARK PARTS ARE LOCATED ON MAIN AMP PC BOARD (B) (AB-3502B)

**MAIN AMP PC BOARD (A)/(B) (AB-3502A/B)**

**NOTE**  
 UNLESS OTHERWISE SPECIFIED  
 ALL RESISTORS IN OHMS 1/4W(J)  
 ALL CAPACITORS IN μF 50WV(Z)

**WARNING:** Δ INDICATES SAFETY CRITICAL COMPONENTS. FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S RECOMMENDED PARTS.  
**AVERTISSEMENT:** Δ IL INDIQUE LES COMPOSANTS CRITIQUES DE SÛRETÉ. POUR MAINTENIR LE DEGRÉ DE SÛRETÉ DE L'APPAREIL, NE REMPLACER LES COMPOSANTS QU'AVEC LES PIÈCES RECOMMANDÉES PAR LE FABRICANT.

**AA-1135L  
 MAIN AMP  
 SCHEMATIC DIAGRAM  
 NO. 2-2 156064**

1 C 8  
2 C 9  
3 C 10  
4 C 11  
5 C 12  
6 C 13

LA-930

PHONO JX-1

FM  
75 OHMS  
300 OHMS  
AM

ANTENNA

ANT 501  
BAR ANTENNA

M 501  
PRESET TUNING METER

M 502  
SIGNAL METER

TAPE 2 J2  
PLAY REC

DIN J1  
REC/PLAY

TAPE 1 J3  
PLAY REC

AUX J4-2

PUSH SW PC BOARD (AB-35103A)

TONE CONTROL PC BOARD (AB-35102)


TOUCH SW PC BOARD (AB-35104)

TOUCH SENSOR PC BOARD (AB-35105)

MULTI FUNCTION PC BOARD (AB-35101A)

VARI CON PC BOARD (AB-35101B)

LED PC BOARD (AB-35103B)



NOTE  
UNLESS OTHERWISE SPECIFIED  
ALL RESISTORS IN OHMS (1/4W1%)  
ALL CAPACITORS IN PFD (50V1%)  
(LL) INDICATES LOW LEAKAGE CAPACITORS

AA-1135L  
SCHEMATIC DIAGRAM  
No. 2-1 1560646A

MAIN AMP PC BOARD (AB-3507A)