




AKAI

DVD/CD/MP3-RECIVER

Model:
ADV-37

SERVICE MANUAL



ADV-37	CASING1	40-15035-031	C-NYLON WASHER 1.5X3.5X0.3MM	1,000
	CASING1	40-15040-030	E-SPRING 1.5X4.0MM/STAINLESS	1,000
	CASING1	41-02004-060	SCREW M2X4 WPH/MS	1,000
	CASING1	41-02005-112	SCREW M2X5 BH/ST BLACK	4,000
	CASING1	41-02006-013	SCREW M2X6 BA/ST	5,000
	CASING1	41-02604-010	SCREW M2.6X4 BH/MS	11,000
	CASING1	41-02604-020	SCREW M2.6X4 KH/MS	6,000
	CASING1	41-02606-010	SCREW M2.6X6 BH/MS	6,000
	CASING1	41-02608-003	SCREW M2.6X8 PA/ST	2,000
	CASING1	41-02608-010	SCREW M2.6X8 BH/MS	1,000
	CASING1	41-02612-110	SCREW M2.6X12 BH/MS BLACK	2,000
	CASING1	41-03016-000	SCREW M3X16 PH/MS	2,000
	CASING1	42-01801-000	DUSTPROOF CLOTHS/WHITE/FOR TOP	1,000
	CASING1	42-01802-000	FIBER WASHER 27X30MM	1,000
	CASING1	42-01803-000	DUSTPROOF CLOTHS/WHITE/FOR BOT	1,000
	CASING1	43-01801-000	HOOK SHAFT	1,000
	CASING1	45-01801-000	HOOK SPRING/0.6MM	1,000
	CASING1	45-01802-000	PUSH OUT SPRING/0.6MM	1,000
	CASING1	49-01801-000	DAMPER 20-24G.CM BLACK/RED	1,000
	CASING1	52-01802-400	BASE/PC/SPRAY BLACK	1,000
	CASING1	52-01803-400	FRONT RING/ABS/SPY BLACK	1,000
	CASING1	53-00010-000	WIRE CLIP/PP/BLACK	2,000
	CASING1	53-01806-000	PUSH POLE/POM	1,000
	CASING1	53-01807-000	MIDDLE GEAR/POM	1,000
	CASING1	53-01808-000	PANEL HOOK/POM	1,000
	CASING1	53-01809-000	DISC BACKLIGHT/PC	1,000
	CASING1	54-01801-410	EJECT KNOB(LIGHT-UP)/SPY BLACK	1,000
	CASING1	60-01801-000	FRONT CABINET/1.0MM	1,000
	CASING1	62-01802-000	TOP COVER/0.6MM	1,000

CASING1	62-01803-000	BOTTOM COVER/0.6MM	1,000	
CASING1	62-01812-000	REAR CABINET/R4	1,000	
CASING1	63-01801-000	HIGH POWER HEATSINK/AL	1,000	
CASING1	67-01804-000	LEFT TURN BRACKET/BLACK	1,000	
CASING1	67-01805-000	RIGHT TURN BRACKET/1.0MM/BLACK	1,000	
CASING1	67-01806-000	LOCATED PLATE/1.0	2,000	
CASING1	67-01809-000	DISK WINDOWS PLATE	1,000	
CASING1	67-01822-000	DECK REAR BRACKET	1,000	
CASING1	67-01823-000	DECK FRONT BRACKET	1,000	
CASING1	71-01801-000	ISULATION PLATE/0.25MM	1,000	
CASING1	71-01802-000	SOCKET SPACER(16P)/PVC/THK.0.5	1,000	S03051000013399
CASING1	72-01801-000	DISK SHADE FOR SHINWA	1,000	
CASING2	40-15040-030	E-SPRING 1.5X4.0MM/STAINLESS	2,000	
CASING2	41-02004-003	SCREW M2.0*4 PA/ST	2,000	
CASING2	41-02010-113	SCREW M2X10 BA/ST BLACK	3,000	
CASING2	43-01802-000	LEFT TURN SHAFT	1,000	
CASING2	43-01803-000	RIGHT TURN SHAFT	1,000	
CASING2	45-01803-000	PRESS SPRING/0.4MM	2,000	
CASING2	45-01804-000	RELEASE SPRING/0.25MM	1,000	
CASING2	51-18101-800	TOP PANEL FOR CD-0181 SPY SIL	1,000	S03021000009959
CASING2	52-18101-400	BOTTOM PANEL SPRAY BLACK	1,000	
CASING2	53-01804-000	LEFT TURN BLOCK/POM	1,000	
CASING2	53-01805-000	RIGHT TURN BLOCK/POM	1,000	
CASING2	53-18101-600	PANEL ADAPTOR SPY BLUE	1,000	S03021000009960
CASING2	53-18102-41G	REL KNOB SPY BLACK/PRINT 427C	1,000	
CASING2	53-18103-000	LEFT BACK LIGHT/ACRYLIC	1,000	
CASING2	53-18104-000	RIGHT BACK LIGHT ACRYLIC	1,000	
CASING2	53-18105-000	REMOTR SENSOR BRACKET	1,000	
CASING2	53-18106-000	LCD BACK LIGHT/WHITE(BOM:J002)	1,000	

CASING2	54-18101-610	PWR KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009961
CASING2	54-18102-610	VOL+ KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009962
CASING2	54-18103-610	VOL- KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009963
CASING2	54-18104-610	□KNOB(L-UP) SPRAY BLUE/ABS	1,000	S03021000009964
CASING2	54-18105-610	□KNOB(L-UP) SPRAY BLUE/ABS	1,000	S03021000009965
CASING2	54-18106-610	DSP KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009966
CASING2	54-18107-610	MOD KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009967
CASING2	54-18108-610	SEL KNOB(L-UP) SPY BLUE/ABS	1,000	S03021000009968
CASING2	54-18109-810	BND KNOB(L-UP) SPY SILVER/ABS	1,000	S03021000009969
CASING2	54-18110-410	EQ KNOB(L-UP) SPY BLACK	1,000	
CASING2	54-18111-410	ST KNOB(L-UP) SPY BLACK/ABS	1,000	
CASING2	54-18112-410	LOU KNOB(L-UP) SPY BLACK/ABS	1,000	
CASING2	54-18113-410	NUMBER KNOB(L-UP)SPY BLACK/ABS	1,000	
CASING2	55-18101-49R	LENS FOR DVD-0181 /AKAI	1,000	S03021000009957
CASING2	67-18101-000	LCD BRACKET /SPY BLACK	1,000	
CASING2	68-18101-000	LEFT SPONGE/3.0MM	1,000	
CASING2	68-18102-000	RIGHT SPONGE/3.0MM	1,000	
CASING2	68-18103-000	SEL SPONGE/BLACK	1,000	
CASING2	68-18104-000	REMOTE SHADE/BLACK	1,000	S03021000010126
CASING2	73-18101-000	LENS TAPE BLACK	1,000	
CHASS100	39-60181-100	DVD0181 MB (BOM:M004)	1,000	
CHASS120	05-00153-000	CHIP CAP F 0.015uF M 0805	2,000	S03021000009716
CHASS120	07-00000-000	CHIP RES 0 OHM 0805	1,000	S03052000013793
CHASS120	07-00000-200	CHIP RES 0 OHM 1206	2,000	S03052000013794
CHASS120	07-00223-000	CHIP RES 22K OHM 0805	1,000	
CHASS130	13-01032-000	WAFER 3P JST2.0	2,000	S03050000013331
CHASS130	27-17020-100	TUNER FM/AM CET-7020FW/E OIRT	1,000	S03021000009715
CHASS140	01-60181-880	IC DVD0181 MCU AKAI	1,000	S03021000009712
CHASS140	32-60181-040	IC LABEL DVD0181 AKAI E/C	1,000	S03021000009713

CHASS200	39-60181-200	DVD0181 KB (BOM:K006)	1,000	
CHASS230	27-91838-000	REMOTE SENSOR TSOP-1838SS3V	1,000	
CHASS430	01-60181-820	IC DVD0181 EPROM AKAI E/C	1,000	S03021000009711
CHASS430	32-60181-040	IC LABEL DVD0181 AKAI E/C	1,000	S03021000009714
CHASS440	02-04148-100	CHIP SW.DIODE RLS4148 LLDS	1,000	S03021000010132
CHASS440	26-60001-000	DVD DECK/SANYO DVD018/0181.	1,000	
CHASS530	02-25401-000	DIODE 1N5401	1,000	
CHASS530	05-20104-000	CER CAP F 0.1uF Z	1,000	
CHASS530	06-16108-000	E.CAP 1000UF 16V 10*16 105C	1,000	
CHASS530	09-30028-200	RING COIL 400UH 1.2MM H	1,000	
CHASS530	11-50180-770	HCD018 FFB 94V0 T1.6 52*40.5	1,000	
CHASS530	22-50180-010	OUTPUT WIRE HCD018 5557A	1,000	
CHASS530	29-25001-000	FUSE 1A 250V 6*30MM	1,000	
CHASS530	29-25015-000	FUSE 15A 250V 6*30MM	1,000	
CHASS530	30-00000-300	FUSE LABEL 15A 250V	1,000	
CHASS530	30-00001-300	FUSE LABEL 1A 250V	1,000	
CHASS530	53-00001-000	FILTER & FUSE BOX /PP	1,000	
CHASS530	67-00003-000	FUSE BRACKET	4,000	
CHASS930	02-40805-051	CHIP LED GREEN 0805 EVERLIGHT	1,000	S03071000016477
CHASS930	02-90355-000	P.LAMP 3V 60mA 3*5.5	1,000	
CHASS930	07-10331-001	CARBON RES 330 OHM 1/16W	1,000	
CHASS930	07-10680-001	CARBON RES 68 OHM 1/16W	2,000	
CHASS930	11-50180-500	HCD018 FB 94V0 T1.6 43.5*87	1,000	
CHASS930	13-42018-040	FLOATING SOCKET DIP16 TCD018	1,000	
CHASS930	15-01105-430	TACT SW KPT1105DM 6X6X4.3 160G	1,000	
CHASS930	15-01107-250	T.SW KPS1107SW 6*3.5*2.5 260G	1,000	
CHASS930	15-51120-090	DETECH SW LD-1120 9.0	1,000	
CHASS930	23-00306-060	LAMP COVER 3*6 BLUE	1,000	
CHASSR00	39-50180-800	HCD018 RC(BOM:R001)	1,000	S03021000009710

CHASSR30	58-01801-04R	REMOTE TOP/AKAI/RED/PC	1,000	S03021000009978
CHASSW0	12-50150-000	FFC C 50P 150MM PH0.5 0.1*0.3	1,000	
CHASSW0	18-40150-020	WIRE UL1007 #28 5+140+5 RED	1,000	
CHASSW0	20-60180-000	JST 2.0 10P RAINBOW #28 80MM	1,000	S03040000012155
CHASSW0	20-60180-010	JST 2.0 5P RAINBOW #28 150MM	1,000	S03040000012156
CHASSW0	22-60180-011	RCA WIRE 2CH/WGR 350MM DVD018	2,000	S03071000016073
CHASSW0	22-60180-020	RCAWIRE VIDEO OUT 320MM	1,000	
PACKING	25-02025-100	BATTERY CR2025 3V/760H 20X2.5	1,000	
PACKING	28-60180-030	CARD RC DVD018 AKAI C&D	1,000	S03021000009977
PACKING	30-00000-200	QC PASSED LABEL	1,000	S03032000011777
PACKING	30-00000-410	WARRANTY LABEL ENG	1,000	
PACKING	30-00080-600	RCA WIRE LABEL AUDIO-F.L	1,000	
PACKING	30-00080-610	RCA WIRE LABEL AUDIO-F.R	1,000	
PACKING	30-00080-620	RCA WIRE LABEL AUDIO-R.L	1,000	
PACKING	30-00080-630	RCA WIRE LABEL AUDIO-R.R	1,000	
PACKING	30-00080-640	OUTWIRE LABEL SPEAKER FRONT L	1,000	S03042000012601
PACKING	30-00080-650	OUTWIRE LABEL SPEAKER FRONT L-	1,000	S03042000012602
PACKING	30-00080-660	OUTWIRE LABEL SPEAKER FRONT R+	1,000	S03042000012603
PACKING	30-00080-670	OUTWIRE LABEL SPEAKER FRONT R-	1,000	S03042000012604
PACKING	30-00080-680	OUTWIRE LABEL SPEAKER REAR L+	1,000	S03042000012605
PACKING	30-00080-690	OUTWIRE LABEL SPEAKER REAR L-	1,000	S03042000012606
PACKING	30-00080-800	OUTWIRE LABEL SPEAKER REAR R+	1,000	S03042000012607
PACKING	30-00080-810	OUTWIRE LABEL SPEAKER REAR R-	1,000	S03042000012608
PACKING	30-00080-820	OUTWIRE LABEL GROUND	1,000	S03042000012609
PACKING	30-00080-830	OUTWIRE LABEL BATTERY+	1,000	S03042000012610
PACKING	30-00080-840	OUTWIRE LABEL IGNITION KEY	1,000	S03042000012611
PACKING	30-00080-850	OUTWIRE LABEL ANTENNA POWER+	1,000	S03042000012612
PACKING	30-50180-691	CONN. ENG FILTER BOX	1,000	S03030000010403
PACKING	30-60180-600	RCA WIRE LABEL VIDEO OUT	1,000	

	PACKING	30-60181-040	FREQ. OIRT DVD AKAI ADV-37	1,000	S03051000013368
	PACKING	40-05008-010	X5.2X8 SPRING WASHER	1,000	
	PACKING	40-05008-030	M5X3 HEXAGON NUT	1,000	
	PACKING	40-05010-010	X5.2X10 PLAN WASHER	1,000	
	PACKING	41-05005-030	SCREW M5X5 RH/MS	4,000	
	PACKING	41-05020-033	SCREW M5X20 RH/ST	1,000	
	PACKING	43-05022-050	SCREW M5X5 HH/MS	1,000	
	PACKING	52-00001-000	CARRING CASE/BLACK/PP	1,000	
	PACKING	62-01804-000	MOUNTING BOX/0.6MM	1,000	
	PACKING	67-00010-000	METAL BAR	1,000	
	PACKING	67-01807-000	LEFT KEY/1.0	1,000	
	PACKING	67-01808-000	RIGHT KEY/1.0	1,000	
	PACKING	68-09010-050	CARRING CASE SPONGE 90X10X5MM	2,000	
	PACKING	68-17545-050	CARRING CASE SPONGE/BLACK	2,000	
	PACKING	70-00801-000	HARNESS RUBBER/BLACK	1,000	
	PACKING	75-01801-000	LEFT POLYFOAM	1,000	
	PACKING	75-01802-000	RIGHT POLYFOAM	1,000	
	PACKING	78-00810-000	POLYBAG 8*10CM PE MARK	1,000	
	PACKING	78-02010-000	POLYBAG 20X10CM PE MARK	2,000	
	PACKING	78-02208-000	POLYBAG 22*8CM PE MARK	1,000	
	PACKING	78-02416-000	POLYBAG 24X16CM PE MARK	1,000	
	PACKING	78-03329-000	POLYBAG 33X29CM PE MARK	1,000	
	PACKING	79-00100-400	COLOR TIE/100MM/BLACK	1,000	
	PACKING	80-18101-008	GIFT BOX/AKAI/DVD0181	1,000	S03021000009970
	PACKING	85-18101-007	INST.MANUAL/AKAI/DVD0181/ENG	1,000	S03021000009971
	PACKING	85-18101-107	INST.MANUAL/AKAI/DVD0181/SPA	1,000	S03051000013376
	PACKING	85-18101-207	INST.MANUAL/AKAI/DVD0181/RUS	1,000	S03051000013377
	PACKING	88-18101-006	CARTON B≡B DVD/TCD0181 E AKAI	0,200	S03021000009972
MO04	CHASS110	01-06008-940	IC ES6008F VIDEO DRIVE	1,000 D	S02123000008833

□□□□	CHASS110	01-16400-920	IC IS42S16400 64M SDRAM	1,000 D	S02123000008834
	CHASS110	05-00104-000	CHIP CAP F 0.1uF M 0805	2,000 D	S03032000011800
	CHASS110	07-00223-000	CHIP RES 22K OHM 0805	1,000 D	S03010000009291
	CHASS110	07-50100-000	RES ARRAY 10 OHM-4 RA03	3,000 D	S02123000008845
	CHASS110	07-50330-000	RES ARRAY 33 OHM-4 RA03	6,000 D	S02123000008846
	CHASS110	07-50470-000	RES ARRAY 47 OHM-4 RA03	2,000 D	S02123000008847
	CHASS110	09-42310-200	CHIP FERRITE BEAD FB310 1206	1,000 D	S03021000009524
	CHASS110	11-60181-000	DVD0181 MB VER02 194.5*139*1.6	1,000 D	S03010000009268
	CHASS110	13-22500-060	FFC CON. 50P 0.5 TOP LOCK	1,000 D	S03011000009486
	CHASS120	02-04148-200	DIODE LL4148 LL-34	15,000 D	S03021000009525
	CHASS120	02-10033-200	ZENER DIODE 3.3V 0.5W LL-34	1,000 D	S03021000009526
	CHASS120	02-10051-200	ZENER DIODE 5.1V 0.5W LL-34	2,000 D	S03021000009527
	CHASS120	02-10062-200	ZENER DIODE 6.2V 0.5W LL-34	8,000 D	S03021000009528
	CHASS120	03-01504-030	CHIP TR. KTA1504SG SOT-23	6,000 D	S02123000008875
	CHASS120	03-03875-030	CHIP TR. KTC3875SG SOT-23	16,000 D	S03032000011801
	CHASS120	03-08050-040	CHIP TR.KTC8050S SOT-23 800MA	1,000 D	S03010000009124
	CHASS120	05-00102-000	CHIP CAP B 1000pF K 0805	5,000 D	S02123000008877
	CHASS120	05-00103-000	CHIP CAP B 0.01uF K 0805	2,000 D	S02123000008878
	CHASS120	05-00104-000	CHIP CAP F 0.1uF M 0805	49,000 D	S02123000008879
	CHASS120	05-00105-000	CHIP CAP B 1UF Z 0805	8,000 D	S02123000008880
	CHASS120	05-00222-000	CHIP CAP B 2200pF K 0805	1,000 D	S02123000008882
	CHASS120	05-00223-000	CHIP CAP F 0.022uF M 0805	41,000 D	S02123000008883
	CHASS120	05-00224-000	CHIP CAP F 0.22uF Z 0805	8,000 D	S02123000008884
	CHASS120	05-00272-000	CHIP CAP B 2700pF K 0805	2,000 D	S02123000008885
	CHASS120	05-00331-000	CHIP CAP B 330PF K 0805	2,000 D	S02123000008886
	CHASS120	05-00471-000	CHIP CAP B 470pF K 0805	2,000 D	S02123000008887
	CHASS120	05-00472-000	CHIP CAP B 4700pF K 0805	6,000 D	S03010000009223
	CHASS120	05-00682-000	CHIP CAP B 6800pF K 0805	2,000 D	S02123000008888
	CHASS120	05-01101-000	CHIP CAP NPO 100pF J 0805	3,000 D	S02123000008889

CHASS120	05-01150-000	CHIP CAP NPO 15PF J 0805	1,000 D	S03032000011805
CHASS120	05-01220-000	CHIP CAP NPO 22pF J 0805	2,000 D	S02123000008891
CHASS120	05-01270-000	CHIP CAP NPO 27pF J 0805	2,000 D	S02123000008892
CHASS120	05-01300-000	CHIP CAP NPO 30pF J 0805	3,000 D	S02123000008893
CHASS120	07-00000-000	CHIP RES 0 OHM 0805	7,000 D	S02123000008894
CHASS120	07-00000-200	CHIP RES 0 OHM 1206	6,000 D	S03041000012321
CHASS120	07-00047-000	CHIP RES 4.7 OHM 0805	1,000 D	S03032000011809
CHASS120	07-00100-000	CHIP RES 10 OHM 0805	7,000 D	S02123000008895
CHASS120	07-00101-000	CHIP RES 100 OHM 0805	13,000 D	S02123000008896
CHASS120	07-00102-000	CHIP RES 1K OHM 0805	34,000 D	S02123000008897
CHASS120	07-00103-000	CHIP RES 10K OHM 0805	41,000 D	S02123000008898
CHASS120	07-00104-000	CHIP RES 100K OHM 0805	21,000 D	S02123000008899
CHASS120	07-00153-000	CHIP RES 15K OHM 0805	4,000 D	S02123000008900
CHASS120	07-00183-000	CHIP RES 18K OHM 0805	4,000 D	S03010000009272
CHASS120	07-00220-000	CHIP RES 22 OHM 0805	1,000 D	S03032000011806
CHASS120	07-00221-000	CHIP RES 220 OHM 0805	2,000 D	S02123000008902
CHASS120	07-00222-000	CHIP RES 2.2K OHM 0805	9,000 D	S02123000008903
CHASS120	07-00223-000	CHIP RES 22K OHM 0805	5,000 D	S02123000008904
CHASS120	07-00224-000	CHIP RES 220K OHM 0805	6,000 D	S02123000008905
CHASS120	07-00271-000	CHIP RES 270 OHM 0805	1,000 D	S02123000008906
CHASS120	07-00273-000	CHIP RES 27K OHM 0805	5,000 D	S03021000009530
CHASS120	07-00330-000	CHIP RES 33 OHM 0805	13,000 D	S02123000008907
CHASS120	07-00331-000	CHIP RES 330 OHM 0805	4,000 D	S03032000011807
CHASS120	07-00332-000	CHIP RES 3.3K OHM 0805	3,000 D	S02123000008909
CHASS120	07-00392-000	CHIP RES 3.9K OHM 0805	3,000 D	S02123000008911
CHASS120	07-00472-000	CHIP RES 4.7K OHM 0805	18,000 D	S02123000008913
CHASS120	07-00473-000	CHIP RES 47K OHM 0805	23,000 D	S02123000008915
CHASS120	07-00562-000	CHIP RES 5.6K OHM 0805	5,000 D	S02123000008914
CHASS120	07-00680-000	CHIP RES 68 OHM 0805	3,000 D	S03032000011808

CHASS120	07-00681-000	CHIP RES 680 OHM 0805	5,000 D	S02123000008916
CHASS120	07-00682-000	CHIP RES 6.8K OHM 0805	1,000 D	S03010000009224
CHASS120	07-00683-000	CHIP RES 68K OHM 0805	1,000 D	S03010000009225
CHASS120	07-00684-000	CHIP RES 680K OHM 0805	1,000 D	S02123000008917
CHASS120	07-00750-000	CHIP RES 75 OHM 0805	1,000 D	S02123000008918
CHASS120	07-00822-000	CHIP RES 8.2K OHM 0805	2,000 D	S02123000008919
CHASS120	09-40022-000	CHIP INDUCTOR 2.2uH 0805	1,000 D	S02123000008982
CHASS120	09-40033-000	CHIP INDUCTOR 3.3uH 0805	1,000 D	S02123000008983
CHASS120	09-42310-200	CHIP FERRITE BEAD FB310 1206	7,000 D	S02123000008984
CHASS130	01-07384-960	POWER AMP. TDA7384	1,000 D	S03021000009590
CHASS130	01-72130-920	IC LC72130 PLL	1,000 D	S02123000008970
CHASS130	01-78L05-990	VOLTAGE REG. 78L05 WS	2,000 D	S02123000008852
CHASS130	01-78L18-990	VOLTAGE REG. 78L18ACZ BK	1,000 D	S02123000008853
CHASS130	02-05822-000	DIODE IN5822 DO-27	2,000 D	S03061000014839
CHASS130	02-10051-000	ZENER DIODE 5.1V 0.5W	1,000 D	S03061000014840
CHASS130	02-10075-000	ZENER DIODE 7.5V 0.5W	1,000 D	S03061000014841
CHASS130	02-10091-000	ZENER DIODE 9.1V 0.5W	3,000 D	S03061000014842
CHASS130	02-10100-000	ZENER DIODE 10V 0.5W	2,000 D	S03061000014843
CHASS130	02-24001-000	DIODE 1N4001	1,000 D	S03061000014844
CHASS130	03-00435-000	TR. BD435 PHILIPS	1,000 D	S02123000008854
CHASS130	03-01240-000	TR. 2SB1240R	2,000 D	S03010000009226
CHASS130	03-08050-010	TR. KTC8050C TO-92	1,000 D	S02123000008971
CHASS130	04-00276-010	27MHZ 16PF 30PPM HC-49/U 85°C	1,000 D	S02123000008973
CHASS130	04-00455-001	4.5MHZ 20PF 30PPM HC-49U/S	1,000 D	S03062000015091
CHASS130	04-00805-001	8MHZ 20PF 30PPM HC-49U/S	1,000 D	S03062000015111
CHASS130	05-00102-000	CHIP CAP B 1000pF K 0805	1,000 D	S03051000013596
CHASS130	06-10107-000	E.CAP 100uF 10V 5*7	13,000 D	S02123000008858
CHASS130	06-10227-000	E.CAP 220uF 10V 6.3*7	8,000 D	S02123000008860
CHASS130	06-10476-000	E.CAP 47uF 10V 4*7	4,000 D	S02123000008861

	CHASS130	06-16106-000	E.CAP 10uF 16V 4*7	17,000 D	S03010000009126
	CHASS130	06-16107-000	E.CAP 100uF 16V 6.3*7	2,000 D	S02123000008862
	CHASS130	06-16226-000	E.CAP 22uF 16V 4*7	1,000 D	S03051000013408
	CHASS130	06-16227-010	E.CAP 220UF 16V 6*8	4,000 D	S03010000009227
	CHASS130	06-16338-000	E.CAP 3300uF 16V 105°C 13*21	1,000 D	S02123000008864
	CHASS130	06-16476-000	E.CAP 47uF 16V 5*7	1,000 D	S02123000008865
	CHASS130	06-50225-000	E.CAP 2.2uF 50V 4*7	8,000 D	S02123000008867
	CHASS130	06-50475-000	E.CAP 4.7uF 50V 4*7	16,000 D	S03010000009233
	CHASS130	07-10022-004	CARBON RES 2.2 OHM 1/2W	1,000 D	S03061000014845
	CHASS130	09-00101-000	DOUBLE COIL 100UH 3A	1,000 D	S02123000008868
	CHASS130	09-00470-000	INDUCTOR 47UH 7.5*11.5	2,000 D	S02123000008974
	CHASS130	09-10100-000	AXIAL INDUCTOR 10UH 3*7	2,000 D	S03061000014846
	CHASS130	09-10330-000	AXIAL INDUCTOR 33UH 3*7	1,000 D	S03061000014847
	CHASS130	13-00022-000	WAFER 2P JST2.0 H	1,000 D	S02123000008869
	CHASS130	13-01052-000	WAFER 5P JST2.0	1,000 D	S02123000008975
	CHASS130	13-01102-000	WAFER 10P JST2.0	1,000 D	S02123000008976
	CHASS130	13-95569-000	OUTPUT SOCKET 5569A-14P 4.2	1,000 D	S02123000008872
	CHASS130	14-35018-000	ANTENNA JACK HCD018 HH	1,000 D	S03032000011848
	CHASS140	01-02313-950	ELEC.VOL PT2313L PTC SO-28	1,000 D	S03030000010278
	CHASS140	01-02401-940	IC AT24C01 SOP8	1,000 D	S02123000008827
	CHASS140	01-03020-990	IC ZA3020 VOL.REG SOP8	2,000 D	S02123000008828
	CHASS140	01-04558-820	DUAL. AMP. KIA4558F	4,000 D	S02123000008829
	CHASS140	01-08728-000	D/A CHANGE WM8728	1,000 D	S03051000013366
	CHASS140	06-16106-090	TAN CAP 10uF 16V M 2.8*3.5	2,000 D	S03061000014848
	CHASS140	06-63476-090	TAN CAP 47uF 6.3V M 2.8*3.5	1,000 D	S03061000014849
K006	CHASS210	02-40805-051	CHIP LED GREEN 0805 EVERLIGHT	21,000 D	S03071000016456
KB□□□	CHASS210	11-60181-510	DVD0181 KB VER00 179.7*41.8*1.	1,000 D	S02123000008959
	CHASS220	01-16431-980	IC uPD16431A LCD DRV	1,000 D	
	CHASS220	05-00104-000	CHIP CAP F 0.1uF M 0805	2,000 D	

CHASS220	06-63476-090	TAN CAP 47uF 6.3V M 2.8*3.5	1,000 D	S02123000008961
CHASS220	07-00100-000	CHIP RES 10 OHM 0805	1,000 D	
CHASS220	07-00101-000	CHIP RES 100 OHM 0805	5,000 D	
CHASS220	07-00102-000	CHIP RES 1K OHM 0805	2,000 D	
CHASS220	07-00103-000	CHIP RES 10K OHM 0805	6,000 D	
CHASS220	07-00104-000	CHIP RES 100K OHM 0805	1,000 D	S03010000009340
CHASS220	07-00122-000	CHIP RES 1.2K OHM 0805	2,000 D	
CHASS220	07-00152-000	CHIP RES 1.5K OHM 0805	2,000 D	
CHASS220	07-00153-000	CHIP RES 15K OHM 0805	2,000 D	
CHASS220	07-00182-000	CHIP RES 1.8K OHM 0805	2,000 D	
CHASS220	07-00222-000	CHIP RES 2.2K OHM 0805	2,000 D	
CHASS220	07-00272-000	CHIP RES 2.7K OHM 0805	2,000 D	
CHASS220	07-00392-000	CHIP RES 3.9K OHM 0805	2,000 D	
CHASS220	07-00470-000	CHIP RES 47 OHM 0805	5,000 D	S03021000009531
CHASS220	07-00471-000	CHIP RES 470 OHM 0805	1,000 D	
CHASS220	07-00472-000	CHIP RES 4.7K OHM 0805	2,000 D	
CHASS220	07-00562-000	CHIP RES 5.6K OHM 0805	2,000 D	
CHASS220	07-00822-000	CHIP RES 8.2K OHM 0805	2,000 D	
CHASS220	09-40100-000	CHIP INDUCTOR 10uH 0805	1,000 D	S03021000009532
CHASS230	15-01107-430	T.SW KPT1107BD 6*3.5*4.3 200G	21,000 D	
CHASS230	23-60181-100	ELEC. RUBBER 88*6*2 DVD0181	2,000 D	S03032000011588
CHASS230	24-50181-101	LCD HCD0181 COLOR TCM-3457	1,000 D	
CHASS240	13-42018-030	FLOATING PLUG SOP16 TCD018	1,000 D	
CHASSR20	01-06122-980	IC SC6122-001 IRC	1,000 D	S03021000009690
CHASSR20	03-03875-030	CHIP TR. KTC3875SG SOT-23	3,000 D	S03021000009691
CHASSR20	05-00223-000	CHIP CAP F 0.022uF M 0805	1,000 D	S03021000009692
CHASSR20	05-01121-000	CHIP CAP NPO 120pF J 0805	2,000 D	S03021000009693
CHASSR20	07-00022-000	CHIP RES 2.2 OHM 0805	1,000 D	S03021000009695
CHASSR20	07-00100-000	CHIP RES 10 OHM 0805	1,000 D	S03021000009694

RO01

□□□□

CHASSR20	11-50180-821	HCD018FIRB VER02 FR4 64*38*1.2	1,000 D	S03071000016443
CHASSR30	02-30305-010	INFRARED LED 3*5 FMY325	3,000 D	S03021000009697
CHASSR30	06-10476-000	E.CAP 47uF 10V 4*7	1,000 D	S03021000009698
CHASSR30	09-94553-100	CERAMIC RESONATOR ZTB455K 2PIN	1,000 D	S03021000009699
CHASSR30	15-01105-250	TSW KPS1105PFY-25 6X6X2.5 250G	1,000 D	S03021000009701
CHASSR30	15-01105-430	TACT SW KPT1105DM 6X6X4.3 160G	9,000 D	S03021000009700
CHASSR30	25-02025-100	BATTERY CR2025 3V/760H 20X2.5	1,000 D	S03021000009704
CHASSR30	41-02008-113	SCREW M2X8 BA/ST BLACK	2,000 D	S03021000009705
CHASSR30	59-01801-000	REMOTE BOT COVER/ABS	1,000 D	S03021000009706
CHASSR30	59-01802-000	BATTERY BRACKET/ABS	1,000 D	S03021000009707
CHASSR30	67-01813-000	BATTERY "+"	1,000 D	S03021000009702
CHASSR30	67-01814-000	BATTERY "-"	1,000 D	S03021000009703
CHASSR30	68-01801-000	DOUBLE TAPE SPONGE/BLACK	1,000 D	S03021000009708
CHASSR30	70-01801-014	RUBBER KNOB/PRINT BLACK	1,000 D	S03021000009709